

# dmf lab

---

## 1. Installation of Sleuth Kit on Linux

### Aim:

To install Sleuth Kit on Linux and analyze allocated & unallocated blocks of a disk image.

### Procedure:

1. Open Terminal → Install Sleuth Kit using `sudo apt install sleuthkit` .
2. Create a disk image using `sudo dd if=/dev/sdb of=diskimage.dd bs=4M` .
3. View image info: `img_stat diskimage.dd` .
4. List data blocks: `mmls diskimage.dd` .
5. Use `fsstat` and `fls` to analyze allocated partitions.
6. Analyze unallocated partitions using `icat` and recover deleted files.

### Diagram:

A simple flow:

Disk → Image Creation → mmls → fsstat/fls → icat (recovery)

### Result:

Sleuth Kit successfully installed and disk image blocks analyzed.

---

## 2. Installation of Sleuth Kit and List All Data Blocks

### Aim:

To list all data blocks using Sleuth Kit tools.

### Procedure:

1. Create disk image using `dd` .

2. Use `mmls` to list block details (start, end, size).
3. Identify unallocated spaces.
4. Verify partitions using `fsstat`.

**Diagram:**

Disk Image → mmls → Block Table Output

**Result:**

All allocated and unallocated blocks listed successfully.

---

## 3. Analyze Allocated and Unallocated Blocks

**Aim:**

To analyze both allocated and unallocated blocks using Sleuth Kit.

**Procedure:**

1. Use `mmls` to identify partitions.
2. Apply `fls` on allocated area to list files.
3. Use `icat` to read deleted/unallocated files.
4. Compare results using recovered file metadata.

**Diagram:**

Allocated → fls  
Unallocated → icat → File Recovery

**Result:**

Allocated and unallocated areas analyzed successfully.

---

## 4. Allocate a Disk Image Using Sleuth Kit

**Aim:**

To allocate a disk image for forensic analysis.

**Procedure:**

1. Install Sleuth Kit.
2. Create a raw disk image ( `.dd` ).
3. Use `mmls` to assign partition boundaries.
4. Mount and analyze image with Autopsy or Sleuth Kit.

**Diagram:**

Disk → Image (.dd) → Allocation → Analysis

**Result:**

Disk image successfully allocated and ready for analysis.

## 5. Data Extraction from Call Logs Using Sleuth Kit

**Aim:**

To extract call log information using Sleuth Kit (Autopsy interface).

**Procedure:**

1. Open Autopsy → Create New Case.
2. Add the phone image file.
3. Select modules (Applications, Contacts, Call Logs).
4. View extracted call records → Export CSV.

**Diagram:**

Autopsy → Case → Modules → Call Logs → Export CSV

**Result:**

Call logs extracted and viewed successfully.

## 6. Allocate Disk Image and Extract Call Logs

**Aim:**

To allocate a phone image and extract call logs.

**Procedure:**

1. Use Sleuth Kit tools to mount disk image.
2. Import image into Autopsy.
3. Run extraction modules for call logs.
4. Export and view call data report.

**Diagram:**

Disk Image → Autopsy → Call Logs Extraction

**Result:**

Call log extraction from allocated disk image completed.

## 7. Data Extraction from SMS and Contacts Using Sleuth Kit

**Aim:**

To extract SMS and contacts from phone image.

**Procedure:**

1. Open Autopsy → Load image.
2. Select `sms.db` and `contacts.db`.
3. Open in SQLite browser → Export to CSV.
4. Analyze SMS and contact records.

**Diagram:**

Autopsy → SQLite → SMS / Contacts → CSV

**Result:**

SMS and contact data extracted successfully.

---

## 8. Install Sleuth Kit and Create SMS & Contacts

### Aim:

To create and analyze sample SMS and contact data.

### Procedure:

1. Install Sleuth Kit.
2. Create sample `sms.db` and `contacts.db`.
3. Import into Autopsy for analysis.
4. Generate CSV report.

### Diagram:

Create DB → Autopsy → Analyze → Report

### Result:

Sample SMS and contact data created and analyzed.

---

## 9. Create Data and Allocate Disk Image

### Aim:

To create sample data and allocate disk image for forensic testing.

### Procedure:

1. Create folder with sample files.
2. Generate image using `dd`.
3. Allocate partitions using `mmls`.
4. Verify structure using `fsstat`.

### Diagram:

Files → dd Image → mmls → fsstat

**Result:**

Data successfully created and allocated for Sleuth Kit.

---

## 10. Install Autopsy and Create Dataset

**Aim:**

To install Autopsy forensic tool and create dataset for analysis.

**Procedure:**

1. Install using `sudo apt install autopsy` .
2. Launch via `autopsy &` .
3. Create new case → add data source.
4. Run modules for dataset creation.

**Diagram:**

Autopsy → Case Creation → Data Source → Dataset

**Result:**

Autopsy installed and dataset created successfully.

---

## 11. Data Extraction in Autopsy Tool

**Aim:**

To extract digital evidence using Autopsy.

**Procedure:**

1. Load image file in Autopsy.
2. Choose "Keyword Search" or "File Analysis".
3. Extract and export relevant artifacts.

4. Save results in report format.

**Diagram:**

Autopsy → Analysis → Extract → Report

**Result:**

Data extracted successfully using Autopsy.

---

## 12. Install Mobile Verification Toolkit (MVT)

**Aim:**

To install MVT for analyzing iOS/Android backups.

**Procedure:**

1. Install dependencies: `python3` , `pip` .
2. Run `pip install mvt` .
3. Test using `mvt-ios --help` or `mvt-android --help` .

**Diagram:**

Dependencies → pip install → Verification

**Result:**

MVT installed successfully on the system.

---

## 13. Reinstall or Update MVT

**Aim:**

To update or reinstall Mobile Verification Toolkit.

**Procedure:**

1. Run `pip uninstall mvt` .
2. Install latest version using `pip install mvt` .

3. Confirm version using `mvt --version`.

**Diagram:**

Uninstall → Install → Verify

**Result:**

MVT reinstalled and verified successfully.

## 14. Process and Parse Records from iOS System

**Aim:**

To parse and process iOS data records for analysis.

**Procedure:**

1. Identify iOS data types (contacts, SMS, logs).
2. Open `sqlite` and `plist` files using browser/editor.
3. Parse and export readable data formats.
4. Combine extracted records for analysis.

**Diagram:**

iOS Backup → SQLite/Plist → Parse → CSV/JSON

**Result:**

iOS records processed and parsed successfully.

## 15. Extract Installed Apps from Android

**Aim:**

To extract APKs of installed applications via ADB.

**Procedure:**

1. Enable Developer Options → USB Debugging.



2. Connect via ADB → `adb devices` .
3. List packages: `adb shell pm list packages -f` .
4. Extract APK using `adb pull` .

**Diagram:**

Phone → ADB → List Apps → Extract APK

**Result:**

All installed apps extracted successfully.

---

## 16. Extract Diagnostic Info Using ADB

**Aim:**

To extract system diagnostics from Android device.

**Procedure:**

1. Connect via ADB.
2. Run `adb bugreport` and `adb logcat` .
3. Save output as text files for analysis.

**Diagram:**

Android → ADB → Logs → Analysis

**Result:**

Diagnostic information extracted successfully.

---

## 17. Generate Unified Timeline of Extracted Records

**Aim:**

To merge multiple extracted logs into a single timeline.

**Procedure:**

1. Gather all log files (call, SMS, system).
2. Sort them by timestamp.
3. Use Excel or forensic tool to plot events chronologically.

**Diagram:**

Logs → Merge → Sort by Time → Timeline

**Result:**

Unified chronological timeline generated successfully.

---

## 18. Extract Installed Applications (Repeat)

**Aim:**

To verify and extract Android installed apps.

**Procedure:**

1. Connect phone via USB.
2. Use `adb shell pm list packages`.
3. Extract required APKs.

**Diagram:**

ADB → List → Extract

**Result:**

Applications extracted and verified successfully.

---

## 19. Extract Diagnostic Information (Repeat)

**Aim:**

To collect Android system diagnostics using ADB.

**Procedure:**

1. Use `adb shell dumpsys` .
2. Save results with `adb bugreport > diag.txt` .
3. Review reports for system health info.

**Diagram:**

ADB → Dumpsys → Bugreport → Analysis

**Result:**

Diagnostic report generated successfully.

---

## 20. Generate Unified Timeline

**Aim:**

To create a combined timeline of mobile activities.

**Procedure:**

1. Combine event logs (SMS, calls, app use).
2. Use spreadsheet or tool to arrange chronologically.
3. Analyze sequence of events.

**Diagram:**

Extracted Data → Merge → Time Sort → Timeline Chart

**Result:**

Unified chronological timeline successfully generated.

---